

Inspection sheet 911 GT3 / GT3 RS / S/T / 718 GT4 RS / Spyder RS as of 2022 model Name: Date: 5/15/24 License No.: Mileage: VIN: Repair Order: WP0AC2A94NS269036 Inspection at 20,000, 40,000, 60,000, 80,000 km/12,000, 24,000, 36,000, 48,000 miles etc. (For descriptions of the individual maintenance tasks, see: PCSS - Porsche Central Service System -> Information media -> Workshop Manual) Note If the mileage for an inspection is not reached, an inspection must be carried out every 2 years at the latest. Every 160 tkm/96 tmls or 12 years Every 120 tkm/72 tmls or 4 years Every 20 tkm/12 tmls or 2 years Every 40 tkm/24 tmls or 4 years Every 80 tkm/48 tmls or 6 years The term 'checking' includes all necessary subsequent work, such as adjustments, readjustments, corrections and topping up, but 718 GT4 RS / Spyder RS does not include repairs, replacements or overhaul of parts or every 60 tkm/36 tmls assemblies. Time-dependent 911 GT3 GT3 RS S/T Measures Windshield wiper/washer system, headlight cleaning system: check function Horn: check function • • • Tires: check tire pressure (TPM) . • . Electronics Diagnostic system: read out fault memory; reset maintenance interval Check actuator travel of brake shoes . Read out the high load detection and document the mileage: ____ km/miles. Observe standard form "additional maintenance instructions for race track use". Create vehicle analysis log (VAL) •

Relevant model line

Inside the vehicle

Particle filter: replace filter element

Door locks: check function

Seat belts: check function and condition



Inspection sheet 911 GT3 / GT3 RS / S/T / 718 GT4 RS / Spyder RS

as of 2022 model Every 160 tkm/96 tmls or 12 years Every 120 tkm/72 tmls or 4 years Every 20 tkm/12 tmls or 2 years Every 80 tkm/48 tmls or 6 years Every 40 tkm/24 tmls or 4 years 718 GT4 RS / Spyder RS every 60 tkm/36 tmls Time-dependent 911 GT3 GT3 RS S/T Measures Check front lid lock and safety hook of the front lid to ensure that they are secure and function properly compartment Luggage Replace air intake pre-filter • • . • Windshield wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on the season, use Porsche • approved windshield cleaner only Check front firewall body drains for debris (every 10 tmls or 1 year) Check wiper blades All headlights: check adjustment • • • • Radiators and air intakes: visual inspection for external contamination • • and blockage Outside the vehicle Brake system: check brake pads and brake discs for wear . • • Vehicles with PCCB: PCCB Brake discs must be checked for wear during every service and whenever brakes pads are replaced using . . special tool VAS 6813 Check central lock on wheels • Drain engine oil Change oil filter • Underbody panels: visual inspection for completeness, secure installation and damage Under the vehicle Tires: check condition Visual inspection for leaks from underneath (oils and other fluids) • • . . Brake lines: visual inspection for damage, routing and corrosion • • • . Brake hoses: visual inspection for damage • • Steering gear: visual inspection of the bellows for damage



Inspection sheet 911 GT3 / GT3 RS / S/T / 718 GT4 RS / Spyder RS

as of 2022 model Every 160 tkm/96 tmls or 12 years Every 120 tkm/72 tmls or 4 years Every 20 tkm/12 tmls or 2 years Every 80 tkm/48 tmls or 6 years Every 40 tkm/24 tmls or 4 years 718 GT4 RS / Spyder RS every 60 tkm/36 tmls Time-dependent 911 GT3 GT3 RS S/T Measures Tie rod joints: check play and dust bellows Drive shafts: visual inspection of the boots for leaks and damage . . • Axle joints: check the play and visually inspect the dust boots for . damage Rear-axle steering: check bellows, dust boots and play on joints • • Check that threaded connections for chassis adjustment at front and rear are secure Check vehicle height • Under the Control boxes for exhaust flaps: check function • • . • Exhaust system: Visual inspection for leaks and damage, check brackets Replace spark plugs • . PDK transmission: change clutch fluid (ATF) PDK transmission: change transmission oil • • • Manual transmission: change oil • • Ancillary unit mounts and chassis: visual inspection of all rubber mountings and boots for damage Replacing clutch • Fill in engine oil Coolant: check level and antifreeze • • compartment Engine Replace drive belt . . Fuel lines and connections: visual inspection Air cleaner: replace filter elements • • • . Check rear firewall body drains for debris (every 10 tmls or 1 year) • .



Inspection sheet 911 GT3 / GT3 RS / S/T / 718 GT4 RS / Spyder RS

as of 2022 model Every 160 tkm/96 tmls or 12 years Every 120 tkm/72 tmls or 4 years Every 20 tkm/12 tmls or 2 years Every 80 tkm/48 tmls or 6 years Every 40 tkm/24 tmls or 4 years 718 GT4 RS / Spyder RS every 60 tkm/36 tmls Time-dependent 911 GT3 GT3 RS S/T Measures Additional work Change brake fluid (use only original Porsche brake fluid) every 2 years Prepare condition report for long-life guarantee Tire sealing compound: check use-by date and replace if necessary Remote control, front seats, electric parking brake and foot brake (also actuation travel), engine, steering, transmission, cruise control, Test drive ESC Off switch, ESC + TC Off switch, PASM switch, Sport switch, Lift switch, sports exhaust system, heating, air conditioning and instruments: check function Oils, fluids: visual inspection for leaks

Signature (technician):	_	

Porsche Center stamp